
HOT IN RUN OR START
FUSE 19 25A
INTERIOR FUSE PANEL
RED/LT GRN
HOT AT ALL TIMES
PCM POWER DIODE
FUSE 10 30A
PCM POWER RELAY
POWER DISTRIBUTION BOX
30
86
85
87
RED/LT GRN
RED/LT GRN
BLK/YEL
YEL
YEL
BLK/YEL
BLK/WHT
RED
S118
BLK/WHT
G108
HOT IN RUN
FUSE 27 15A
INTERIOR FUSE PANEL
PPL/ORG
S207
PPL/ORG
TRANSMISSION CONTROL SWITCH
TAN/WHT
TRANS CTRL SW 29 TAN/WHT
SHIFT SOL 2 1 PPL/ORG
MIL 2 PNK/LT GRN
TR1 3 YEL/BLK
PPL/ORG 1
PNK/LT GRN 2
YEL/BLK 3
AIR CONDITIONING
RED
S123
RED 4
RED 5
RED 6
RED 7
DATA LINK 13 PPL
DATA LINK (-) 15 PNK/LT BLU
DATA LINK (+) 16 TAN/ORG
S205
S206
PPL 13
PNK/LT BLU 10
TAN/ORG 2
DATA LINK CONNECTOR
FUEL LEVEL IN 12 YEL/WHT
SHIFT SOL 1 27 ORG/YEL
INSTRUMENT CLUSTER SYSTEM
ORG/YEL 8
PNK/WHT 9
AIR SUSP INPUT 19 ORG/BLK
ELECTRONIC SUSPENSION SYSTEM
CASE GND 25 BLK
G203
A/C 41 PPL
AIR CONDITIONING SYSTEM (HTR-A/C ASSY)
HO2S 2 SIG 35 RED/LT GRN
MAF SIG RTN 36 TAN/LT BLU
TRANS TEMP 37 ORG/BLK
ECT SENS 38 LT GRN/RED
IAT SENS 39 GRY
FUEL PUMP MON 40 DK GRN/YEL
RED/LT GRN 10
TAN/LT BLU 11
ORG/BLK 12
LT GRN/RED 13
GRY 14
DK GRN/YEL 15
FUEL FLOW RATE 43 LT BLU/PNK
NOT USED 14 LT BLU/BLK
CKP SENSOR (+) 21 BLK/PNK
CKP SENSOR (-) 22 GRY/YEL
EVR CTRL 47 BRN/PNK
TACHOMETER 48 TAN/YEL
TR2A 49 LT BLU/BLK
TR4A 50 WHT/BLK
IGN COIL 1 26 DK BLU/LT GRN
IGN COIL 2 52 RED/LT BLU
PWR GND 24 BLK/WHT
PWR GND 51 BLK/WHT
NOT USED
LT BLU/PNK 16
BRN/PNK 17
TAN/YEL 18
LT BLU/BLK 19
WHT/BLK 20
RED/YEL 21
S105
POWERTRAIN CONTROL MODULE
S118
RED/LT BLU
SPARK PLUGS
RED/LT GRN
DK BLU/LT GRN
SPARK PLUGS
PNK/WHT
SPARK PLUGS
RED/LT GRN
RED/YEL
SPARK PLUGS
RED/LT GRN
BLK/WHT
G108
IGNITION COIL 1 & 2
IGNITION COIL 3 & 4
RADIO NOISE CAPACITOR
CRANKSHAFT POSITION SENSOR SHIELD
GRY/YEL
BLK/PNK
CRANKSHAFT POSITION SENSOR
BLK
S108
BLK
G203

129476