

SHOCK ABSORBERS - SUPERIDE

CHEVY / GMC 4WD

MODEL	YEAR	ACTUAL LIFT	FRONT	FACTORY AUXILIARY	REAR	
AVALANCHE ½ TON <div style="text-align: right; font-size: small;"> (Knuckle Series Systems) (Bracket Systems) </div>	2001-06	0-2"	88110 (90)		—	
		2¾-3½"	88120 (90)		—	
		6"	88100 (90)		—	
		6-7½"	88080 (79,90)		—	
AVALANCHE ¾ TON	2001-06	6-7½"	85285		85160	
BLAZER / JIMMY (Full Size), TAHOE / YUKON	1969-72	0-2"	85050		85100	
		3-5"	85100		85140	
		6-8"	85140		85150	
	1973-91	0-1"	85050	85080	85100 (30)	
		2-2½"	85080	85100	85100 (30)	
		3-4"	85100	85140	85140 (30)	
		5-8"	85140	85150	85150 (30)	
	1992-94	0-2½"	85030		85120	
		4-6"	85114		85151	
	HUMMER H2	2001-05	6"	85285		85150
LUV MINI PICKUP	1979-83	0-1"	85200 (68)		85070 (68)	
PICKUP ½, ¾ TON (6-LUG WHEELS) (except '01-06 1500HD)	1969-72	0-2"	85050		85100	
		3-5"	85100		85140	
		6-8"	85140		85150	
	1973-87	0-1"	85050	85080	85100 (30)	
		2-2½"	85080	85100	85100 (30)	
		3-4"	85100	85140	85140 (30)	
		5-8"	85140	85150	85150 (30)	
		10-12"	85150	85150	85160 (30)	
	1988-98	0-2½"	85030		85120	
		4-6"	85114		85151	
	1999-06	0-2"	88110 (90)		85150	
		2¾-3½"	88120 (90)		85150	
		5-6"	88100 (90)		85160	
		6-7½"	85080 (79)		85160	
	PICKUP 1500HD	2001-06	0"	—		85150
			6-7½"	85285		85160
PICKUP ¾ TON (8-LUG WHEELS) (Including '01-06 K-2500HD)	1969-72	0-2"	85050		85100	
		3-5"	85100		85140	
		6-8"	85140		85150	
	1973-87	0-1"	85050	85080	85100 (30)	
		2-2½"	85080	85100	85100 (30)	
		3-4"	85100	85140	85140 (30)	
		5-8"	85140	85150	85150 (30)	
		10-12"	85150	85150	85160 (30)	
	1988-98	0-2½"	85030		85120	
		5-7"	85114		85151	
	1999-06	0"	—		85150	
		6-7½"	85285		85160	
PICKUP 1 TON <div style="text-align: right; font-size: small;"> (88-92 CREW CAB) </div>	1973-87	0-2"	85050	85080	85140	
		3-4"	85100	85140	85150	
		5-6"	85140	85150	85150	
	1988-99	0-2"	85030		85120	
		5-7"	85114		85151	
	1999-06	0"	—		85150	
6-7½"		85285		85160		
S10 / S15 PICKUP, S10 BLAZER / S15 JIMMY, SONOMA (Except ZR2)	1983-03	0-1"	85040		85110	
		2-3"	85070 (68)		85120	
		6"	85070		85148	
S10 / S15 PICKUP, S10 BLAZER / S15 JIMMY, SONOMA ZR-2 / HIGHRIDER	1994-03	0-1"	85040		85120	
		2-3"	85070 (68)		85146	
		6"	85116		85146	

NOTES:

30...If rear shocks' upper mounting studs cannot be reused, order (1) #60460 - pair shock studs.

68...These shocks and steering stabilizers have a small diameter body designed to be used in limited space applications. Order boots for 1.81" cylinders.

79...Will fit vehicles with the Superlift suspension lift system only.

90...Gas pressurized shock cylinder.

SHOCK ABSORBERS - SUPERIDE

DODGE 4WD

MODEL	YEAR	ACTUAL		FACTORY	
		LIFT	FRONT	AUXILIARY	REAR
RAIDER With 4-cylinder	1984-91	0-1"	85201 (68)		85080
RAIDER With V6	1989-91	0-1"	85201 (68)		85050

DODGE 2WD

D-50, RAM 50, ARROW	1979-94	0-1"	85201 (68)		85070
DAKOTA	1986-96	0-1"	85201 (68)		85110
	1997-01	0"	85201 (68)		85116
PICKUP 1/2, 3/4 TON	1961-71	0-2"	85141		85141
PICKUP 1/2, 3/4, 1 TON (Except cab & chassis)	1972-93	0-2"	85231		85141
	1994-01	0-1"	85232		85129
RAMCHARGER	1972-93	0-2"	85231 (89)		85141
VAN B100, B150, B200, B250, B300, B350, B1500, B2500, B3500 (Except 9000GVW)	1970-00	0"	85231 (89)		85080

FORD 4WD

BRONCO	1966-77	0"	85240		85050	
		1-2"	85250		85080	
		3-4"	85280		85100	
		5-6"	85280		85140	
	1978-79 (Uses one each front shock)	0"	85270 (6) 85250 (34)	85270 (6) 85250 (34)		85050
		1-2"	85280 (6) 85270 (34)	85280 (6) 85270 (34)		85080
		3-4"	85300 (6) 85280 (34)	85300 (6) 85280 (34)		85140
		5-6½"	85310 (6) 85300 (34)	85310 (6) 85300 (34)		85140
		1980-96	0	85230 (34)	85250 (6)	
		1-2"	85240 (34)	85270 (6)		85100
		2½-3½"	85250 (34)	85280 (6)		85100
		4-5"	85270 (34)	85280 (6)		85140
		6"	85280 (34)	85300 (6)		85140
BRONCO II	1984-90	0"	85230		85100	
		1-2"	85240		85140	
		3-4"	85270		85140	
		5-6"	85280		85150	
EXCURSION	1900-03	0"	85140		85151	
EXPEDITION (Except air leveling)	1997-03	0"	85233		85116	
EXPLORER (Except '95)	1990-94	0"	85230		85120	
		1-2"	85240		85151	
		3-4"	85270		85151	
		5½"	85280		85120 (79)	
	1995-01	0	—			85146
		4	85331			85151
EXPLORER, SPORT-TRAC	2001-05	0	—		85146	
		4"	85331		85151	
F-100, F-150 PICKUP (Including '01 Supercrew)	1970-76	0-2"	85082		85280	
		3-4"	85103		85300	
		5-7"	85141		85310	
	1977-79	0-1"	85250 (34)	85270 (6)		85280
		2-3"	85270 (34)	85280 (6)		85300
		4-5"	85280 (34)	85300 (6)		85300
		6-7"	85300 (34)	85310 (6)		85310
		8-9"	85310 (34)	85310 (6)		85310
	1980-96	0	85230 (34)	85250 (6)		85100
		1-2"	85240 (34)	85270 (6)		85140
		2½-3½"	85250 (34)	85280 (6)		85140
		4-5"	85270 (34)	85280 (6)		85150
		6"	85280 (34)	85300 (6)		85150
	1997-03	0"	85233			85310
		4-5"	85285			85140 (79)
	2004-06	0-2½"	—			85150
		4½"	—			85150

NOTES:

6....Ahead of axle.

34...Behind axle.

68...These shocks and steering stabilizers have a small diameter body designed to be used in limited space applications. Order boots for 1.81" cylinders.

79...Will fit vehicles with the Superlift suspension lift system only.

89...Slight grinding of lower control arm is required.

90...Gas pressurized shock cylinder.

SHOCK ABSORBERS - SUPERIDE

FORD 4WD

MODEL	YEAR	ACTUAL		FACTORY			
		LIFT	FRONT	AUXILIARY	REAR		
F-250	(HIGH BOY)	1966-77	0"	85450		85100	
			2-4"	85460		85140	
	(LOW BOY)	1977½-79	0-1"	85450		85280	
				2-4"	85460		85310
		1980-86	0"	85240 (77)		85100	
				1-3"	85270 (77)		85140
			4"	85280 (77)		85150	
	(LEAF SPRING)	1987-97	0-1"	85080		85100	
				2-3"	85100		85140
				4-6"	85140		85150
	(TORSION BAR, 7-LUG WHEEL)	1997-98	0"	85233		85310	
	(SUPER DUTY)	1999-04	0-2"	85100		85150	
				4-6"	85140		85160
				7-8"	85150		85160
				10"	85160		85150
	(SUPER DUTY)	2005-06	0-2"	88510 (90)		85150	
				4"	88510 (90)		85160
				6"	88520 (90)		85160
			8"	88540 (90)		85160	
F-350 (Except Dually)	1980-85	0"	85240 (77)		85100		
			1-3"	85270 (77)		85140	
			4"	85280 (77)		85150	
	1986-98	0-1"	85100		85100		
			2-3"	85140		85140	
			4"	85140		85150	
	(SUPER-DUTY)	1999-04	0-2"	85100		85150	
				4-6"	85140		85160
				7-8"	85150		85160
	(SUPER DUTY)	2005-06	0-2"	88510 (90)		85150	
				4"	88510 (90)		85160
				6"	88520 (90)		85160
			8"	88540 (90)		85160	
F-350 (Dually)	1986-98	0-1"	85100		85140		
			2-4"	85140		85150	
	(SUPER-DUTY)	1999-04	0-2"	85140		85150	
				4-6"	85140		85160
				7-8"	85150		85160
RANGER	1983-97	0"	85230		85140		
			1-2"	85240		85140	
			3-4"	85270		85150	
			5-6"	85280		85150	
	1998-05	0"	—		85100		
			3-4"	85331		85150	
FORD 2WD							
BRONCO II	1984-90	0"	85230		85080		
			1-2"	85240		85100	
EXPEDITION (Except air leveling)	1997-01	0"	85210		85116		
EXPLORER	1990-94	0"	85230		85120		
	1995-01	0	—		85146		
F-150	1965-69	0-1"	85240		85050		
			2"	85250		85080	
	1970-79	0-1"	85240		85270		
			2"	85250		85280	
	1980-96	[-4"]	85230		85080		
		0"	85230		85090		
			1-2"	85240		85120	
			2½-3½"	85250		85140	
			4-5"	85270		85140	
	1997-03	0"	85280		85150		
	0"	85210		85300			

SHOCK ABSORBERS - SUPERIDE

FORD 2WD

MODEL	YEAR	ACTUAL LIFT	FRONT	FACTORY AUXILIARY	REAR
F-250, F-350 PICKUP (92-97 W/8600GVW & UP)	1980-98	0"	85230		85090
		1-2"	85240		85120
		2½-3½"	85250		85140
		4-5"	85270		85140
		6"	85280		85150
	(7-LUG WHEELS) (SUPER-DUTY)	1997-99	0"	85210	
	1999-04	0"	85230		85140
RANGER	1983-97	[-3"]	85230		85100
		0"	85230		85100
		1-2"	85240		85140
		3-4"	85270		85140
		5"	85280		85150
	1998-05	0"	—		85100
VAN E-100, E-150	1975-91	0"	85230		85270
	1992-00	0"	85230		85270
VAN E-250, E-350	1975-91	0"	85240		85280
	1992-00	0"	85230		85280

INTERNATIONAL

SCOUT 80, 800	1961-68	0-1"	85050		85250
SCOUT 800	1969-71	0-1"	85050		85250
SCOUT II	1971-81	0"	85250		85050
		1-2"	85270		85100
		3-4"	85280		85140

ISUZU 4WD

AMIGO	1990-95	0"	85230		85090
P'UP	1981-88	0"	85200 (68)		85090
	1989-95	0"	85230		85090
RODEO	1990-95	0"	85230		85280
	1996-97	0"	—		85280
TROOPER II	1984-86	0"	85200 (68)		85090
	1987-88	0"	85200 (68)		85280
	1989-91	0"	85230		85280
	1992-00	0"	85230		85051

ISUZU 2WD

AMIGO	1990-96	0"	85230		85090
HOMBRE	1996-99	0"	—		85120
P'UP	1981-95	0"	85200 (68)		85090
RODEO	1990-95	0"	85230		85280
	1996-97	0"	—		85280
TROOPER II	1992-00	0"	85230		85051

JEEP 4WD

CHEROKEE, WAGONEER XJ (Except ZJ Grand Series)	1984-01	0-1½"	85272		85081
		2-3"	85290		85081
		4-5"	85303		85121
MB, M38, CJ2A, CJ3A, CJ3B	1941-64	0"	85030		85030
		1-2½"	85050		85050
CJ5, CJ6, CJ3A, CJ3B	1953-75	0-1½"	85030		85050
		2-3"	85050		85080
		4"	85080		85100
CJ5, CJ7, SCRAMBLER (CJ8)	1976-81	0-1½"	85030		85080
		2-3"	85050		85100
		4"	85080		85140
	1982-86	0-1½"	85050		85080
		2-3"	85080		85100
		4"	85100		85140
COMANCHE (MJ)	1986-92	0-1½"	85272		85100
		2-3"	85290		85112
		4-5"	85303		85080

NOTES:

68...These shocks and steering stabilizers have a small diameter body designed to be used in limited space applications. Order boots for 1.81" cylinders.

77...1980-82 F-250 without reusable shock studs, order (1) #60465 - pair shock studs.

90...Gas pressurized shock cylinder.

SHOCK ABSORBERS - SUPERIDE

JEEP 4WD

MODEL	YEAR	ACTUAL LIFT	FRONT	FACTORY AUXILIARY	REAR
COMANDER (XK)	2006	4"	—		88200
GRAND CHEROKEE (WJ, ZJ)	1993-98	0-1½"	85272		85080
		2-3"	85290		85112
		4-5"	85303		85140
	1999-01	0-2"	85272		85085
GRAND CHEROKEE (WK)	2005-06	4"	—		88200
LIBERTY (KJ)	2001-05	0-2"	—		85090
J10, J20 PICKUP	1974-89	0-1"	85050		85050
		2-3"	85080		85080
		4"	85100		85100
J200, J300, J2000, J3000, J4000 PICKUP	1963-73	0-1"	85090		85050
JEEPSTER, COMMANDO	1967-69	0-1"	85040		85040
	1970-73	0-1"	85040		85070 (68)
WAGONEER (Except 63-65 IFS)	1963-73	0-1"	85090		85030
WAGONEER, CHEROKEE, GRAND WAGONEER (Full Size)	1974-91	0-1"	85050		85050
		2-3"	85080		85080
		4"	85100		85100
WRANGLER (TJ)	1997-06	0	85274		85052
		1-2"	85286		85092
		3-4"	85307		85117
		5-6"	85350		85131
WRANGLER (YJ)	1987-96	0"	85280		85050
		1-2"	85300		85080
		3-4"	85300		85100

JEEP 2WD

CHEROKEE, WAGONEER XJ (3" Maximum Rear Lift)	1984-01	0-1½"	85272		85081
		2-3"	85290		85081
COMANCHE (MJ)	1986-92	0-1½"	85272		85100
		2-3"	85290		85140
COMANDER (XK)	2006	4"	—		88200
GRAND CHEROKEE (WJ, ZJ)	1993-98	0-1½"	85272		85080
		2-3"	85290		85112
		4-5"	85303		85140
	1999-01	0-2"	85272		85085
GRAND CHEROKEE (WK)	2005-06	4"	—		88200

MAZDA 4WD

B2600 PICKUP	1987-93	0-1"	85230		85111
B3000, B4000 PICKUP	1994-97	0"	85230		85140
		1-2"	85240		85140
		3-4"	85270		85150
		5-6"	85280		85150
	1998-02	3-4"	85321		85150
NAVAJO	1991-94	0"	85230		85120
		1-2"	85240		85151
		3-4"	85270		85151
		5½"	85280		85120 (79)

MAZDA 2WD

B2000 PICKUP	1972-84	0"	85210		85450
	1986-93	0"	85230		85070 (68)
B3000, B4000 PICKUP	1994-97	[-3"]	85230		85080
		0"	85230		85100
		1-2"	85240		85140
		3-4"	85270		85140
		5"	85280		85150
	1998-02	0"	—		85100

MITSUBISHI 4WD

PICKUP	1983-95	0-1"	85201 (68)		85100
MONTERO (Except electronic adjustable shocks & sport)	(LEAF SPRING REAR)	1983-89	0-1"	85201 (68)	85080
	(COIL SPRING REAR)	1989-91	0-1"	85201 (68)	85050
	(LEAF SPRING REAR)	1992-99	0-1"	—	85220

NOTES: 68..These shocks and steering stabilizers have a small diameter body designed to be used in limited space applications. Order boots for 1.81" cylinders

79..Will fit vehicles with the Superlift suspension lift system only.

SHOCK ABSORBERS - SUPERIDE

MITSUBISHI 2WD

MODEL	YEAR	ACTUAL LIFT	FRONT	FACTORY AUXILIARY	REAR
PICKUP	1983-95	0-1"	85201 (68)		85070 (68)

NISSAN / DATSUN 4WD

PATHFINDER	1987-95	0-2"	85230		85090	
PICKUP	1980-81	0-1"	85200 (68)		85480 (68)	
	1982	0-1"	85200 (68)		85090	
	1983-86	0-1"	85200 (68)		85090	
		1½-2½"	85230		85100	
	(HARDBODY)	1986½-97	0-1"	85200 (68)		85090
			1½-2½"	85230		85100
(FRONTIER)	1998-02	0-1"	—		85080	

NISSAN / DATSUN 2WD

PICKUP	1971-78	0-1"	85200 (68)		85480 (68)	
	1979-82	0-1"	85200 (68)		85480 (68)	
	1983-86	0-1"	85200 (68)		85480 (68)	
	(HARDBODY)	1986½-97	0-1"	85200 (68)		85070 (68)
			1½-2½"	85230		85080
	(FRONTIER)	1998-02	0-1"	—		85050

SUZUKI 4WD

LJ10, SJ10, LJ410, SJ410	1978-88	0-1"	85240		85030
LJ413	1982-85	0-1"	85240		85030
	1985-87	0-1"	85250		85050
SAMURAI / SANTANA	1986-95	0-2"	85240		85030
		3"	85250		85080

TOYOTA 4WD

4-RUNNER	1984-85	0"	85240		85400	
		1-2"	85250		85400	
		3"	85271		85410	
		4-5"	85281		85410	
		6-7"	85301		85155	
	1986-89	0-1½"	85220		85400	
		4-5"	85260		85410	
	1990-95	0-1½"	85220		85282	
		4-5"	85260		85302	
	LANDCRUISER FJ40	1960-74	0-1"	85030		85050
2-3"			85080		85090	
1975-83		0-1"	85030		85100	
		2-3"	85080		85140	
LANDCRUISER STATION WAGON	1969-79	0-1"	85270		85100	
	1980-87	0-1"	85273		85080	
	1988-90	0"	85273		85400	
PICKUP	1979-83	0"	85240		85100	
		1-2"	85250		85100	
		3"	85271		85140	
		4-5"	85281		85140	
		6-7"	85301		85150	
	1984-85	0"	85240		85400	
		1-2"	85250		85400	
		3"	85271		85410	
		4-5"	85281		85410	
		6-7"	85301		85155	
	1986-95	0-1½"	85220		85400	
		4-5"	85260		85410	
	T-100	1993-98	0-1½"	85220		85140
			4-5"	85260		85150
	TACOMA	1995-04	0-1½"	—		85400
TOYOTA 2WD						
TUNDRA	99-05	0-1½"	—		85281 (96)	
4-RUNNER	90-95	0-1½"	85220		85282	
		4-5"	85260		85302	
PICKUP	70-83	0-1"	85210		85070 (68)	
	84-94	0-1"	85231		85070 (68)	
T-100	93-98	0-1½"	85220		85400	
TACOMA	95-98	0-1"	—		85080	