


ENGINE COMPARTMENT FUSE/RELAY BOX (LOCATED ON LH SIDE OF ENGINE COMPARTMENT)



FRONT VIEW

Fuse	Amps	Circuits Protected
ALTERNATOR	15	Charging System
HOOD LAMP/ DAYTIME RUN- NING LAMPS	15	Courtesy Lamps, Daytime Running Lamps
FOG LAMP	20	Fog Lamps
FUEL PUMP	20	Electronic Engine Control

Maxi-Fuse	Amps	Circuits Protected
EEC PWR	30	Electronic Engine Control
ELEC. SHIFT	20	Electric Shift Control
FUSE PNL	40	Courtesy Lamps, Radio Memory, Power Distribution, Power Mirrors, Stop Lamps, Park/License Lamps
FUSE PNL	60	Horn/Cigar Lighter, Power Lumbar Seats, Hazard Lamps, Premium Sound Radio, Flash-to-Pass
IGN	60	Power Distribution
PWR LCKS	20	Power Door Locks

BLADE FUSE COLOR CODING	
AMPERE RATING	HOUSING COLOR
4	Pink
5	Tan
10	Red
15	Light Blue
20	Yellow
25	Natural
30	Light Green

MAXI-FUSE CARTRIDGE COLOR CODING	
AMPERE RATING	HOUSING COLOR
20	Yellow
30	Light Green
40	Amber
50	Red
60	Blue