
HOT AT ALL TIMES
HOT IN START OR RUN
HOT AT ALL TIMES
HOT IN RUN
POWER DISTRIBUTION BOX
FUSE 14 60A
FUSE 19 10A
FUSE 15 5A
FUSE 25 5A
JUNCTION BOX FUSE/RELAY PANEL
30 C243
25 C243
3 C243
ORG/YEL
RED/YEL
LT BLU/BLK
TAN/RED
S213
RED/YEL
3
BRAKE PEDAL POSITION (BPP) SWITCH
12 C250
INSTRUMENT CLUSTER
G106
ANTI-LOCK BRAKE INDICATOR
5.6K OHM
22K OHM
2
1
RED/LT GRN
PNK/ORG
S201
PNK/ORG
G206
S108
4 LT GRN/YEL
3 ORG/YEL
C1041
11 C253
DK GRN
RED/LT GRN
1 DK GRN
15 RED/LT GRN
14 TAN/RED
COMPUTER DATA LINES SYSTEM
12 LT BLU
INSTRUMENT CLUSTER SYSTEM
LT BLU/WHT
5 LT BLU/WHT
S225
LT BLU/WHT
7 DATA LINK CONNECTOR
GENERIC CONTROL MODULE (GEM), INSTRUMENT CLUSTER, JUNCTION BOX FUSE/RELAY PANEL, OVERHEAD TRIP COMPUTER (OTC) MODULE, POWERTRAIN CONTROL MODULE, SPEED CONTROL SERVO AMPLIFIER
VSS (+)
16 GRY/BLK
REAR SENSOR (HIGH)
9 RED/PNK
REAR SENSOR (LOW)
21 LT GRN/BLK
RIGHT FRONT SENSOR (HIGH)
10 YEL/RED
RIGHT FRONT SENSOR (LOW)
22 YEL/BLK
LEFT FRONT SENSOR (HIGH)
11 TAN/ORG
LEFT FRONT SENSOR (LOW)
23 TAN/BLK
7 TAN/LT GRN
C1040
ANTI-LOCK BRAKE SYSTEM (ABS) MODULE
21 TAN/LT GRN
S201
TAN/LT GRN
24 DK GRN/YEL
GENERIC ELECTRONIC MODULE (GEM)
BRAKE FLUID LEVEL SWITCH
TAN/BLK
TAN/ORG
YEL/BLK
YEL/RED
LT GRN/BLK
RED/PNK
LEFT FRONT ANTI-LOCK BRAKE SENSOR
RIGHT FRONT ANTI-LOCK BRAKE SENSOR
DIFFERENTIAL SPEED SENSOR (DSS)
BLK
S102
BLK
G104

124548