

HOT IN START OR RUN

NOTE: THE SEAT BELT INDICATOR RECEIVES POWER FROM PIN1 OF C216 ON VEHICLES NOT EQUIPPED WITH TACHOMETER.

* RABS ONLY
** 4WABS ONLY

